



Before You Begin

Read These Instructions Completely and Carefully

WARNING

Risk of electric shock

- Disconnect power from the luminaire and follow proper lockout/tagout procedures before beginning installation or maintenance. Contact a qualified electrician for installation.
- *Venture Lighting* LED Highbay Light Fixtures require 120V 60Hz input voltage. The installer is responsible to determine whether the proper voltage is run to the luminaire being installed / serviced.
- Ensure the electrical receptical is properly grounded.
- *Venture Lighting* LED Highbay Light Fixture is IP64 rated for wet locations.
- This device is not intended for use with emergency exits.
- This device is not intended for use with dimmers.
- MIN 75°C supply conductor must be used.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.



Upgrade Instructions

STEP 1: Disconnect power from the luminaire and follow proper lockout/tagout procedures before beginning installation or maintenance.

STEP 2: Screw the hook onto the top of the fixture. (Figure 1)

STEP 3: Secure the fixture to a mounting surface by tightening the mounting screw. (Figure 2)

STEP 4: Connect the plug into a 120V 60Hz receptical.

STEP 5: Power can be restored to the system.




Figure 1




Figure 2



(877) 281-1233

Fax: (877) 294-2829
2451 Enterprise Parkway East
Twinsburg, OH 44087 USA
E-mail: venture@adlt.com

VentureLighting.com





Avant que tu commences

Lisez ces instructions complètement et attentivement

ATTENTION

Risque de choc électrique

- Débranchez l'alimentation du luminaire et suivez les procédures de verrouillage / étiquette appropriées avant de commencer l'installation ou la maintenance. Contactez un électricien qualifié pour l'installation.
- *Venture Lighting* Les haute lumière de la baie LED nécessitent une tension d'entrée de 120V 60Hz. L'installateur est responsable de déterminer si la tension appropriée est exécutée sur le luminaire installé / entretenu.
- Assurez-vous que la prise électrique est correctement mise à la terre.
- *Venture Lighting* Les haute lumière de la baie est IP64 pour les endroits humides.
- Cet appareil n'est pas destiné à être utilisé avec des sorties de secours.
- Cet appareil n'est pas destiné à être utilisé avec des gradateurs.
- Un conducteur d'alimentation minimum de 75°C doit être utilisé.
- Ce produit doit être installé conformément au code d'installation applicable par une personne familière avec la construction et l'exploitation du produit et les dangers inhérents.



Instructions de mise

- 1: Débranchez l'alimentation du luminaire et suivez les procédures de verrouillage / étiquette appropriées avant de commencer l'installation ou la maintenance.
- 2: Vissez le crochet sur le dessus de l'appareil. (Figure 1)
- 3: Fixez le luminaire sur une surface de montage en serrant la vis de montage. (Figure 2)
- 4: Brancher la fiche dans une prise 120V 60Hz.
- 5: L'alimentation peut être restaurée dans le système.




Figure 1




Figure 2



(877) 281-1233

Fax: (877) 294-2829
2451 Enterprise Parkway East
Twinsburg, OH 44087 USA
E-mail: venture@adlt.com

VentureLighting.com

